

INSTALLATION GUIDE

PLASTERBOARD

Breathaplasta Smooth is ideal as a healthy skim coat applied directly to conventional gypsum plasterboard without the need for a primer. Breathaplasta Smooth is a quick and easy lime plaster. It's easy to use and sets within 60-90min.

Important notes for use on plasterboard:

- Ensure plasterboard is conventional gypsum plasterboard (ivory coloured paper).
- Specialist plasterboard requires a primer to be used before plastering. Examples include: moisture resistant (green), fire resistant (pink), and acoustic (blue).

Mix

Water required



Add 1 x 20kg bag of Smooth to approx. 8 litres of clean water.

Mix Time



Mix the plaster using a paddle mix for approx. 3 minutes.

Apply

Primer



Apply a primer to prepare the surface of the plasterboard.

Apply

Two coats



Apply at least 2 coats of Smooth. Each coat should be approx. 1-2mm thick.

Set

Setting time



Setting time per coat of Smooth is approx. 60-90 minutes.

Finish

Use clean trowel



Use a trowel to polish the surface until a super smooth finish is achieved.

breathAplasta



Good for our buildings



Good for our health



Good for our planet

Equipment Required:

Breathaplasta Smooth, clean water, primer, hawk, trowel and plastering tools.

Surface preparation:

No treatment or priming is required before applying plaster to conventional plasterboard. Specialist plasterboard requires a primer to be used.

Recommended plaster thickness:

Approx. 4mm total thickness.

Recommended plaster application:

1. Base coat of Smooth at 1-2mm.
2. Top coat of Smooth at 1-2mm.
3. After the top coat is set, return to the plaster and use a trowel to polish the surface until a super smooth finish is achieved. Do not spray more water onto the plaster and be careful not to overwork it at this stage.

Coverage per 20kg Universal bag:

Approx. 10m² at 3mm thickness

Setting time per coat:

Approx. 60 - 90 minutes